



Sway Bar Install

Tear down

- 1) Remove the links that are connected to your arm and to the sway bar.
- 2) Remove the sway bar brackets, there are 4 nuts on the inside of the frame that need to be removed. Then on the driver side slide the sway bar assembly out.

Install

- 1) Take your Sandcraft sway bar mounts and bolt them into the frame in the original location. Orientate so the shoulder of the bushing is facing inside or toward each other on each side.
- 2) The sway bar tube will slide thru the first mount. Now is the time to slide both of the collars (supplied) over the tube. Then slide tube thru the other side.
- 3) At this point you will need a tape measure to center the bar to the mounts. Measure from the bracket to the end of the tube and make sure there is a even amount of tube on each side.
- 4) Now attach the Sandcraft Sway Bar Arms to the tube so that the logo is facing the outside. Now tighten the pinch bolt on the arm where it attaches to the tube.
- 5) The links will now be attached to the Sway Bar Arm first. Tighten bolts connecting links to the Arm.
- 6) Now the bottom link on one side will bolt into the Trailing arm location. The other link arm will need to be adjusted to be able to bolt in to the trailing arm.
- 7) Set both adjustable links to the same over all length from center to center of the bolts. Tighten down the jam nuts and double check all work