



## Polaris RZR XP Turbo S Front Winch Bumper # S3160-WB

# PARTS LIST

ITEM	PART #	DESCRIPTION	QTY
	S3160	Front Winch Bumper Assembly	1
	30071-2	Winch Mount Plate	1
	30065-5	Upper Mount Nut Retainer	1
	11268	Upper Mount Grommet	2
		Finishing Plug	2
	S3BK-PRZRTS-FB	Bolt Kit	1

# INSTALLATION

- 1.) Mount winch to 30071-2 Winch Mount Plate using hardware provided with your winch.
- 2.) Mount 30065-5 Upper Mount Nut Retainer to inside of frame rail using 8mm nut.
- 3.) Mount winch/30071-2 to unit using 11268 – Upper Mount Grommet, (2) 12mm bolts, and (2) 10mm bolts. Use stock tow hook nut retainer when fastening 10mm bolts.
- 4.) Mount bumper assembly using (4) 10mm bolts, (4) 10mm flat washers, and (4) 10mm lock washers.
- 5.) Tighten hardware and install finishing plugs into tube ends of bumper.